

TOP2003 Software Installation

Install on PC with operating system WINDOWS98SE/ME/2000:

1. Disconnect TOP2003 (Do not connect TOP2003);
2. Run the Setup.exe file on CD, follow the instruction to continue;
3. Reboot the PC after the final confirmation of the installation;
4. After Windows starts, please connect the TOP2003 with the cable given. The rectangular head connect directly to the USB port of PC and the square head connect to TOP2003. (Please do not connect through a USB interface with no power supply. This will degrade the driving power.)
5. After the red LED light of the TOP2003 on, click to run the “start/program/TOP2003.exe” application. The green light will on after 5-10 seconds. Everything is then ready for normal operation.

Install on PC with operating system: WINDOWS XP:

Owing to the complexity of the XP edition and the specialty of the USB working on XP, installation may be not so smooth compared with WINDOWS98SE/ME/2000. Several times may have to be tried before success. Since Cypress cannot recognize XP, some XP users may not be able to install this software. Nevertheless, most of the XP users can install this software according to the past experience from our valuable customers.

1. Disconnect TOP2003 (Do not connect TOP2003);
2. Run the Setup.exe file on CD, follow the instruction to continue;
3. Reboot the PC after the final confirmation of the installation. After reboot, connect the TOP2003 to the USB interface with the cable provided. The red light will on. Bottom right-hand corner of the screen displays “New hardware USB device found”.

A dialog box will come up of screen as follows:

New hardware found Hardware now searching, please wait . . . Cypres EZ-USB(2131Q/2131S/2135S)-EEPROM missing
--

"EEPROM missing" is a normal information.

4. If USB device found, screen displays:

Thank you for using new hardware
This helps you to install the software :
Cypres EZ-USB(2131Q/2131S/2135S)-EEPROM missing ...
o auto installation of software (recommend) (I)
o install from the table list or specified location (advanced) (S)

Choose “Auto installation of software (recommend) (I)”and click “Next”.

5. “hardware installation” dialog displays, below information appears:

Installing software for hardware device:
Cyress EZ-USB Sample Device
Without Windows Label Test, the compatibility with Windows XP cannot be verified.
Continue to install this software may lead to immediate or later unstable of
Windows system.

Ignore the above warning and click “Continue (C)”to next step.

6. “Find new hardware found” dialog displays “Find new hardware finished”, click “Finished” to end the installation.
7. Disconnect TOP2003 with USB interface and then reboot Windows.
8. After the start of Windows, please connect the TOP2003 with the cable given. The rectangular head connect directly to the USB port of PC and the square head connect to the TOP2003. After the red LED light of the TOP2003 on, click to run the “start/program/TOP2003.exe”application. The green light will on after 5-10 seconds. Everything is ready for normal operation. Please do not continue to read or write if the green light off, otherwise, “ Read USB bad! ”error will occur.
9. If “ Cannot open device” message appears, it means that the driver program is not successfully installed. Please repeat the above procedure 1-8 to install again.